



1. UNDER NO CIRCUMSTANCES SHALL SCREENINGS BE USED IN PLACE OF BEDDING SAND.
2. CUT ALL STONES WITH A SAW TO ENSURE SMOOTH CUTS WITH NO CHIPS IN STONE.
3. WHEN ESTABLISHING SIZE OF PAVED AREAS SUCH AS CROSSWALK WIDTHS, TREE PLANTING AREAS AND PAVING STRIP ALONG CURB, SET DIMENSIONS TO THE NEAREST FULL PAVING MODULE.
4. ALL DIMENSIONS ARE IN MILLIMETRES.



## STREETSCAPE PAVINGSTONE

REV No.	DATE: APR 2023
<b>2</b>	SCALE: N.T.S.

**P1360**